

# Installing Jeneer Pump Type 2 Sensor Assembly

# Installing Sensor Assembly



Install sensor into the sensor tube. Push the sensor until it is flush with the bottom of the pump head.

# Installing Sensor Assembly



Fill the cavity with the 3M super silicone until it is flush with the top or the sensor tube nut. Thread the bottom of the cable gland into the sensor tube nut.

# Installing Sensor Assembly



Using the slip pliers tighten the bottom nut of the sensor cable gland. Pull on the sensor cable until you feel the top of the sensor bottom out. Tighten top cable gland and remove excess silicone

# Testing the Sensor Assembly



Connect the sensor cable to the module and activate it. Move the float up and down the sensor tube and check to be sure the sensor is activating by monitoring the LED. Move the float to the top of the pump head and wait for 20 seconds until the LED shows PLY. Then push the pump on button and the LED should read PLN. This indicates the sensor is working properly.